



M3PRO 80 MID ENGLISH

Three-phase Digital Energy Meter

Direct connection 80 A

Operating instructions

The Energy Meter provides all relevant measures for the evaluation of an electrical network: I, U, PF, F, THD% Powers (displayed for each phase and 3 phase) and Imported/Exported Active/Reactive Energies.

All models have the 0.25-5(80) A current range, with 2 tariffs and with IR lateral communication available.



The built-in communication depends of the model:


Code	Model	Communication
888-304; 888-304CH*	M3PRO 80 MID	2 SO Pulse outputs MID certified
888-305; 888-305CH*	M3PRO 80 Modbus MID	Built in RS-485 Modbus RTU MID certified
888-306; 888-306CH*	M3PRO 80 M-Bus MID	Built in M-Bus (1 unit Load) MID certified

(*) For Swiss market only active energy on display

RISK OF ELECTRIC SHOCK, BURNS OR EXPLOSION
This device must be installed and maintained ONLY by qualified and duly authorized personnel.

During its installation, be sure there is no voltage applied.


Front of the Energy Meters



- UP button: to scroll pages and change parameters
- DOWN button: to scroll pages and change parameters
- MENU/ESC button: to change menu and stop modification procedure of a parameter
- OK button: to confirm the modification of a parameter

Device Switch-on


- When the device is switched on, the firmware version and the model appear on the display for one second. (Preliminary Page)




Display Back light

- If no button is pushed for 40 seconds, the display goes back to the Main Page and the backlight is switched off.
- The first button pushing does not change the page but is used to switch the backlight on.

Main Energy Page




- 1: Appears if V (L-N) >= 92 VAC
- 2: Three-phase energy
- 3: "Imported" / "Exported" flowing power direction
- 4: working tariff
- 5: Three-phase Active Energy register
- 6: Corresponding Partial Energy register
- 7: Energy Unit



(* access can be protected by Password (see Password chapter)

Partial Energies Reset Procedure



Password
In Configure Menu it is possible to protect the access to sub-menus of Selection Menu by a password.

Password can be enabled (ON password) or disabled (OFF password), the default value is OFF

Once requested, to enter the password user must push both UP button and DOWN button at the same time for 4 seconds


Phase Sequence Error

In case the cabling sequence is wrong, this message appears. In this condition, the Energy Meter continues to measure and to increase the Energy Registers, but its calculation is not correct.
By pushing OK button for 5 seconds, this message disappears until next restart


Unrecoverable Internal Errors

In case the display shows these messages, the device has got a malfunction and must be replaced

Dimension




Sealable terminal covers



Wiring diagram


The Energy Meter has **OVERVOLTAGE CATEGORY III** (according to IEC 62052-31 that refers to IEC 60664-1 Ed. 2.0:2007), hence its direct connection to the Public Electricity Grid is not allowed. The Energy Meter is intended for INDOOR installation only (according to EN 50470-1 and IEC 62052-31). The Energy Meter must be installed on a DIN rail and inside a cabinet with a protection degree (IP rating) equal to (or better than) IP51.

(N) Neutral wire must be connected to the meter



- SO output 1 (pin 6-7) proportional to Active Imported Energy
- SO output 2 (pin 4-5) proportional to Reactive Imported Energy
- or
- SO output 1 (pin 6-7) proportional to Active Imported Energy under Tariff T1
- SO output 2 (pin 4-5) proportional to Active Imported Energy under Tariff T2

M3PRO 80 Modbus MID



- 1: Tariff input, internally opto-isolated (4kV). Applying 230 VAC ($\pm 20\%$), the running tariff toggles to T2, and T2 Energy Counter Registers are incremented
- L1: Input connection for phase 1.
- L2: Input connection for phase 2.
- L3: Input connection for phase 2.
- L3: Input connection for phase 3.
- N: Neutral connection.

- 2: Opto-isolated S01 pulses output
- 4-5: Opto-isolated S02 pulses output

Modbus

- 4: Modbus Network. Short this pin with pin 5 to apply 120 Ohm termination.
- 5: Modbus network. D1
- 6: Modbus network. D0
- 7: Modbus network. Common

M-Bus

- 4-6: M-Bus network terminals.
- 5-7: M-Bus network repeated terminals. These terminals are internally connected to terminals 4-6.

Terminal Description

S0
6-7: Opto-isolated S01 pulses output
4-5: Opto-isolated S02 pulses output

Modbus
4: Modbus Network. Short this pin with pin 5 to apply 120 Ohm termination.

5: Modbus network. D1


6: Modbus network. D0

7: Modbus network. Common

M-Bus
4-6: M-Bus network terminals.

5-7: M-Bus network repeated terminals. These terminals are internally connected to terminals 4-6.

Main Menu



Note: Main Page and consequently page sequence could be different, according to the flowing power and working tariff!

Parameters in S0 model

PLS 250 kWh
Pulses per kWh
• In direct connected models, the following values are available:
1, 2, 5, 10, 20, 50, 100 or 200.
• The default value is 200.

PLS 80 tEne
Pulse time length
• Duration of ON pulse for S0 outputs:
30 to 100 ms.
• The default is 100 ms

PLS In - Out kWh
S0 outputs configuration mode
■ In - Out
■ S01 proportional to Imported Active Power
■ S02 proportional to Exported Active Power
■ Act-React
■ S01 proportional to Imported Active Power
■ S02 proportional to Imported Reactive Power
■ TAR1-TAR2
■ S01 proportional to Imported Active Power under T1
■ S02 proportional to Imported Active Power under T2

• Password Enabled/Disabled

OFF PRSSuJ0rd

Parameters in models with Modbus on-board

Addr 138
Modbus Address
Selectable in the range 1 ... 247.
The default address is 1.

bRud rAEE 9600
Modbus Baud Rate
Available Baud Rates are:
1200, 2400, 4800, 9600, 19200 and 38400.
The default baud rate is 19200.

Modbus Parity
Available Parity are None, Even and Odd.
The default Parity is Even.

Modbus Number of Stop Bits (1 or 2)
The default number of Stop Bits is 1

• Password Enabled/Disabled

Parameters in models with M-Bus on-board


Addr 138
M-Bus Primary Address
Selectable in the range 1 ... 250.

M-Bus Baud Rate
Available Baud Rates are:
300, 600, 1200, 2400, 4800 and 9600.
The default baud rate is 2400.

Unique M-Bus Secondary Address, not modifiable

• Password Enabled/Disabled

Connectable IR Communication Modules



Cable stripping length and max terminal screw torque

Main terminals - Screw driver P22


15.5 mm -> 2 Nm

Tariff and communication terminals


Screw driver blade 0.6x3.5 mm

9 mm -> 0.5 Nm

MID certified



Note



Technical Data

Data in compliance with CLC/TR 50579, EN 62059-32-1, EN 50470-1, EN 50470-3

Direct connection	Pulse output	Direct connection built-in communication Modbus / M-Bus
General characteristics		
• Housing	DIN 43880	4 modules DIN rail
• Mounting	EN 60715	35 mm 70 mm 412 g
• Depth		
• Weight		
Operating features		
• Connectivity	to three-phase network	n° wires 4 4
• Storage of energy values and configuration	internal FLASH memory	- yes
• Display tariffs identifier	for active energy	n° 2 T1 and T2 T1 and T2
Approval (according to EN 50470-1, EN 50470-3)		
• Reference Voltage Un	Line to Neutral VAC	230 230
• Reference Current (Iref)	VAC	400 400
• Minimum Current (Imin)	A	5 5
• Maximum Current (Imax)	A	0.25 0.25
• Starting Current (Isat)	A	80 80
• Reference Frequency (fref)	A	0.015 0.015
• Number of Phases (number of wires)	-	50 50
• Certified Measures	kWh class	3 (4) 3 (4)
• Accuracy	Active Energy (accor. to EN 50470-3) and Active Powers	→ kWh, ← kWh → kWh, ← kWh
Supply Voltage and Power Consumption		
• Operating Supply Voltage range	VAC	92 ... 276 / 160 ... 480
• Maximum Power Dissipation (Voltage circuit)	VA (W)	≤ 2 (0.6) ≤ 2 (0.6)
• Maximum VA burden (Current circuit) @ Imax	VA	≤ 0.7 ≤ 0.7
• Voltage Input Waveform	-	AC AC
Overload capability		
• Voltage	continuous, phase/phase	VAC 480 480
	second phase/phase	VAC 800 800
	continuous, phase/N	VAC 276 276
	1 second, phase/N	VAC 300 300
	continuous	A 80 80
	Temporary (10 ms)	A 2400 2400
Measuring Features		
• Voltage range	phase/phase	VAC 160 ... 480 160 ... 480
	phase/N	VAC 92 ... 276 92 ... 276
• Current range (secondary winding)	A	0.015 ... 80 0.015 ... 80
• Frequency range	Hz	45 ... 65 45 ... 65
• Measured Quantities	-	kWh kWh
Display features		
• Display type	LCD	9 (2 Decimal) 9 (2 Decimal)
• Active Energy	mm	6 x 3 6 x 3
• Running Tariff	min. ... max. kWh	0.01 ... 999999.99 0.01 ... 999999.99
• Display refresh period	s	1 11 or 12 11 or 12
Safety		
• Protective class	II	II II
• AC voltage test (EN 50470-3, 7.2)	V	4 4
• Degree of pollution	-	2 2
• Operational voltage</td		



M3PRO 80 MID

DEUTSCH

Digitaler 3-Phasen Energierzähler

Direktanschluss, 80 A-Anschluss

Bedienungsanleitung

Der Energierzähler misst alle für die Überprüfung eines Stromnetzes relevanten Größen: I, U, PF, F, THD %, Leistungsfaktoren (Anzeige der einzelnen Phasen und der 3 Phasen), bezogene/abgegebene Wirk-/Blindleistung.

• Die Stromstärke aller Modelle reicht von 0,25 bis 5 (80 A), sie verfügen über 2 Tarife, und seitlich kann ein IR-Kommunikationsmodul angeschlossen werden.



Das eingebaute Kommunikationsmodul hängt vom Modell ab:

Kode	Modell	Kommunikationsmodul
888-304; 888-304CH*	M3PRO 80 MID	2 SO Impulsausgänge MID-zertifiziert
888-305; 888-305CH*	M3PRO 80 Modbus MID	Eingebauter RS-485 Modbus RTU MID-zertifiziert
888-306; 888-306CH*	M3PRO 80 M-Bus MID	Eingebauter M-Bus (1 Einheitslast), MID-zertifiziert

(*) Für den Schweizer Markt wird nur aktive Energie angezeigt

⚠️ STROMSCHLAG-, VERBRENNUNGS- UND EXPLOSIONSGEFAHR

Dieses Gerät darf NUR von einem Elektriker installiert und gewartet werden.

Sicherstellen, dass während der Installationsarbeiten kein Strom anliegt.

Frontal der Energierzähler



- Peiltaste nach OBEN: Zum Blättern durch die Menüseiten und Ändern der Parameter
- Peiltaste nach UNTEN: Zum Blättern durch die Menüseiten und Ändern der Parameter
- MENU/ESC-Taste: Zum Wechseln des Menüs und Abbrechen, wenn ein Parameter geändert wurde
- OK-Taste: Zum Bestätigen eines geänderten Parameters

Einschalten des Gerätes


• Nach dem Einschalten des Gerätes werden für eine Sekunde die Firmware-Version und das Modell angezeigt. (Vorhergehend angezeigte Seite)



• Wenn länger als 40 Sekunden keine Taste gedrückt wird, kehrt das Display zur Startseite zurück und die Beleuchtung schaltet sich aus.

• Beim ersten Tastendruck wird die Seite nicht gewechselt, sondern die Beleuchtung des Displays eingeschaltet.

Start-Seite




1: Wird angezeigt, wenn V (L-N) >= 92 VAC
2: Drehstrom
3: Richtung des Stromflusses:
"Importierte" (bezogene) / "Exportierte" (abgegebene) Energie

4: Arbeitstafel
5: 3-Phasen Wirkenergie-Zähler
6: Zugehörige Teil-Energierzähler
7: Energieeinheit

(*) Zugang kann durch Passwort geschützt werden (siehe Kapitel Passwort)

Startmenü



■ Hinweis: Die Startseite und folglich auch die Reihenfolge der Seiten können abhängig vom fließenden Strom und dem aktuellen Tarif anders sein

Auswahlmenü

Durch Drücken von auf einer beliebigen Seite des Startmenüs

• Wenn diese Seite angezeigt wird, können die Teiltäler zurückgesetzt werden (die Hauptenergien können nicht zurückgesetzt werden).

3-Phasen Energie-Liste

Partial EnergIES

OK

• Durch nochmaliges Drücken der OK-Taste können die Teiltäler zurückgesetzt werden.

• Wenn die MENU/ESC-Taste gedrückt wird oder länger als 40 Sekunden keine Taste gedrückt wird, wird der Vorgang abgebrochen und erneut die Seite "Energ Reset?" (Energierzähler Zurücksetzen?) angezeigt.

EnergIES

OK

EnergIES

OK