

# DTR<sup>®</sup> 8511



**Digital transformer ratiometer**

Thank you for purchasing a **DTR® 8511 Digital transformer ratiometer** flexible current sensor.

For best results from your instrument:

- **read** these operating instructions carefully,
- **comply** with the precautions for use.

	WARNING, risk of DANGER! The operator must refer to these instructions whenever this danger symbol appears.
	WARNING, risk of electric shock. The voltage applied to parts marked with this symbol may be hazardous.
	Equipment protected by double insulation.
	Ground / earth.
	Battery.
	Fuse.
	USB socket
	Indicates Important information to acknowledge.
	The CE marking certifies the product's compliance with the European Low Voltage Directive (2014/35/EU), Electromagnetic Compatibility Directive (2014/30/EU), and Restriction of Hazardous Substances Directive (RoHS, 2011/65/EU and 2015/863/EU).
	The rubbish bin with a line through it indicates that, in the European Union, the product must undergo selective disposal in compliance with Directive WEEE 2012/19/EU. This equipment must not be treated as household waste.

#### Definition of measurement categories

- Measurement category IV corresponds to measurements taken at the source of low-voltage installations.  
Example: power feeders, counters and protection devices.
- Measurement category III corresponds to measurements on building installations.  
Example: distribution panel, circuit-breakers, machines or fixed industrial devices
- Measurement category II corresponds to measurements taken on circuits directly connected to low-voltage installations.  
Example: power supply to electro-domestic devices and portable tools.

# CONTENTS

<b>1. PRECAUTIONS FOR USE</b> .....	<b>4</b>
<b>2. FIRST USE</b> .....	<b>5</b>
2.1. Receiving your shipment .....	5
2.2. Product packaging .....	5
2.3. Accessories .....	6
2.4. Replacement Parts .....	6
<b>3. PRODUCT FEATURES</b> .....	<b>7</b>
3.1. Description .....	7
3.2. Features .....	8
3.3. Inside cover label .....	9
3.4. Control features .....	10
3.5. Cable identification .....	12
<b>4. SPECIFICATIONS</b> .....	<b>13</b>
4.1. Reference conditions .....	13
4.2. Electrical specifications .....	13
4.3. Mechanical specifications .....	14
4.4. Environmental specifications .....	15
4.5. Safety specifications .....	15
4.6. Electromagnetic compatibility .....	15
<b>5. DISPLAY FUNCTIONS</b> .....	<b>16</b>
5.1. The menu system .....	16
5.2. Test Result Screens .....	36
5.3. Error messages .....	38
5.4. Battery warning messages .....	39
5.5. Battery error messages .....	40
<b>6. OPERATION</b> .....	<b>41</b>
6.1. Data Measurement .....	41
6.2. Measuring Data .....	41
6.3. Power up instrument .....	42
6.4. Running a test from the instrument .....	43
6.5. Instrument user interface (UI) .....	47
6.6. Running Tests From the DTR Transfer application software .....	47
6.7. Tips for making precise ratio measurements .....	47
6.8. Ratio Test - 1:1 .....	48
<b>7. CONNECTIONS</b> .....	<b>49</b>
7.1. Connection Diagrams .....	49
7.2. Polyphase Connections .....	50
<b>8. DATAVIEW® &amp; DTR TRANSFER APPLICATION SOFTWARE</b> .....	<b>51</b>
8.1. Installing DataView® .....	51
8.2. DTR Transfer application software .....	52
<b>9. MAINTENANCE</b> .....	<b>54</b>
9.1. Cleaning .....	54
9.2. Charging the batteries .....	54
9.3. Updating the firmware (USB Flash Upload) .....	56
<b>10. WARRANTY</b> .....	<b>57</b>
<b>11. COMPLIANCE</b> .....	<b>58</b>
11.1. Applicable Standards .....	58
11.2. Certifications .....	58
11.3. Term Definitions .....	58
11.4. Abbreviations .....	59

# 1. PRECAUTIONS FOR USE

---

This instrument complies with safety standard IEC/EN 61010-2-030.

Carefully read and understand all required precautions when using this instrument. Failure to comply with these safety instructions can create a risk of electric shock, fire, and explosion; resulting in destruction of the instrument, injury to the user, and damage to the facility. If the instrument is used other than as specified in this manual, the protection provided by the instrument may be impaired.

- This instrument is protected from accidental voltages of not more than 50 V with respect to earth. The guaranteed level of protection of this equipment may be compromised if used in a manner not specified by the manufacturer.
- Read the instruction manual completely and follow all safety information before attempting to use or service this instrument.
- The Digital Transformer Ratiometer DTR® 8511 is designed for use on **de-energized (dead)** transformers only. Make sure the test sample is completely disconnected from AC power and is fully discharged.
- Only qualified personnel should use the DTR® 8511.



**WARNING: Always make sure the circuit is fully discharged before attaching any test cables.**

---

- The DTR® 8511 must not be used in a manner in which any of its components (including test cables) are relied upon to provide protection from electric shock. No high voltage insulation/protection is provided by any component of the DTR® 8511.
- Do not touch, adjust, or reposition test cables while the DTR® 8511 is conducting a test.
- Use caution on any apparatus: potentially high voltages and currents may be present and pose a shock hazard.
- Safety is the responsibility of the user.
- Never open the instrument while it is connected to AC power or when test cables are connected to transformers, equipment, circuits, etc.



**NOTE: Before** using the instrument for the first time, it is recommended to fully charge the battery by leaving it connected to the charger for **10 hours**. This initial charge helps condition the battery and extend its overall service life (see § 9.2).

---

## 2. FIRST USE

### 2.1. RECEIVING YOUR SHIPMENT

Upon receiving your shipment, make sure that the contents are consistent with the packing list. Notify your distributor of any missing items. If the equipment appears to be damaged, file a claim immediately with the carrier and notify your distributor at once, giving a detailed description of any damage. Save the damaged packing container to substantiate your claim.

### 2.2. PRODUCT PACKAGING

#### PRODUCT PACKAGING



DTR® 8511



Set of 4,6 m leads w/ Alligator Clips



Extra Large Classic Tool Bag



USB Type-C Wall Power Adapter



Cable - 1,80 m USB 3.1 Type-C PD to Type-C



Cable - 3 m USB Type-C to Type-A



AC Power Adapter w/Cord



USB Drive (DataView)



Quick Start Guide

Also Included: Internal rechargeable AA NiMH batteries

## **2.3. ACCESSORIES**

Small Classic Tool Bag (33x25x24 cm)

Extra Large Carrying Bag w/Rubber Bottom

Leads - Set of 0,7 m

## **2.4. REPLACEMENT PARTS**

Extra Large Classic Tool Bag (46x23x30 cm)

Leads - Set of 2, 4,6 m

Safety alligator - Black (1000 V, CAT IV, 15 A, UL V2)

Safety alligator - Red (1000 V, CAT IV, 15 A, UL V2)

Latches - Replacement set of 2

Adapter - USB Type-C Wall Power Adapter

Adapter - Replacement AC Power Adapter w/cord

Cable - 3 m Type-C to Type-A USB 2.0 Full Speed (12 Mbps)

Cable - 1,8 m USB Type-C 3.1 PD to Type-C USB 2.0 Full Speed (12 Mbps)

For the accessories and spares, consult our web site:

[www.chauvin-arnoux.com](http://www.chauvin-arnoux.com)

## 3. PRODUCT FEATURES

---

### 3.1. DESCRIPTION

The DTR® 8511 is an easy-to-use Digital Transformer Ratiometer capable of measuring ratios on single phase transformers with high precision. It is a lightweight, rugged, portable instrument designed for on-site testing of transformers (power, VT/PT, and CT).

A typical application of the DTR® 8511 is checking transformer ratio winding values prior to installation by comparing nameplate values to actual values for ratio accuracy reasons.

Operation of the DTR® 8511 is fully automatic. No user calibration, range selection, hand cranking or tedious balancing is required.

**During each Ratio test cycle, the DTR® 8511 automatically checks for:**

- Reversal of H and X leads
- High current

**During each Continuity test cycle, the DTR® 8511 automatically performs a Pass (Continuity) / Fail (No Continuity) check for::**

- Continuity in the H lead
- Continuity in the X lead

**Upon completion of a test cycle, the DTR® 8511 displays:**

- **Turns Ratio:** The ratio of the primary to secondary voltage at the transformer terminals due to test current.
- **Test Current:** The RMS excitation current in the primary side winding due to test current during negligible loading of the associated X winding.
- **Deviation:** If Nameplate is enabled, indicates the deviation value from nameplate ratio in %. If Nameplate is disabled deviation displays as **N/A**.

The user can also save Nameplate voltages and compare the results as the data is being gathered. The data can later be downloaded to a PC and analyzed using the DataView® software application which is included with the product.

DataView® allows full control of the instrument. If the DTR® 8511 is connected to a PC through an isolated USB interface, data can be downloaded to the PC and analyzed using the DTR Transfer application software.

The instrument supports the ability to upload firmware updates via USB Flash Upload (see § 9.3).

The firmware will support the following languages:

- US English
- French
- German
- Italian
- Spanish
- Portuguese

The instrument is powered by:

- The (6) internal rechargeable AA NiMH batteries, for running tests in the field.
- The external USB power via the included AC/DC USB-C wall power adapter. This adapter can accept between 100 V<sub>AC</sub> to 240 V<sub>AC</sub>.
- The 12.0 V<sub>DC</sub> input connector via an external AC power adapter with barrel connector, used for when the batteries are depleted.



**NOTE:** Testing can only run if the batteries have enough power, or the 12 V<sub>DC</sub> AC power adapter is plugged in.

**NOTE:** When running tests from the DTR Transfer application software, all testing is disabled when connected to USB only. In this scenario, the below screen will display:




Figure 2

You must connect the supplied 12 V<sub>DC</sub> AC power adapter to proceed with testing.



**NOTE:** The DTR® 8511 utilizes an advanced, low-voltage, step-down measurement technique in which the primary side windings are subjected to test current. This results in greater operator safety and the ability to test a wider array of transformer types and sizes.

## 3.2. FEATURES

### 3.2.1. Main Features

- Removable leads
- IP 53 rated (cover closed)
- Ratio measurements up to 8000.0:1 VT/PT or 1000.0:1 CT
- 12 V<sub>DC</sub> power operation via external 100 V<sub>AC</sub> to 240 V<sub>AC</sub> to 12 V<sub>DC</sub> 4.3 A power adapter with standard barrel connector
- Programmable nameplate ratios
- Deviation calculations (when Nameplate is enabled)
- Remote control via the included DataView® software
- Lead reversal detection
- Continuity testing
- Open Primary detection
- Open Secondary connection
- 9,801 storage locations
- Fully charge battery life to run 500 VT/PT tests
- Auto power off (configurable)
- CE approved

### 3.2.2. Model Features

- Output (H): (1) 5-pin connector for signal injection (H) compatible with test leads for DTR® 8510.
- Input (X): (1) 3-pin connector for signal sense (X) compatible with test leads for DTR® 8510.
- Large (6) button rubber keypad: Up, Down, Left, Right, Enter and Test
- Excitation Current Measurements (C)
- Ratio Deviation Measurements (D)
- H/X Lead Reversal Check
- Internal Transformer Library (P,S)
- Safety: IEC 61010-2-030, CE
- Fixed Output Voltages (VT/PT) 30 V<sub>AC</sub>
- Fixed Output Voltages (CT) 5 V<sub>AC</sub>
- Fixed Test Frequency (64 Hz)
- Test Current (2 A max)
- Numbered of Stored Tests (99 objects, 99 tests)
- Run tests while charging batteries (via 12 V<sub>DC</sub> input only)
- Isolated USB Type-C 2.1 port (for charging and communication)
- 12 V<sub>DC</sub> input using a standard barrel connection (11 x 5.5) mm
- Internal Memory for Data Storage
- 4-line Alphanumeric Display (4 x 20)
- Backlight
- (6) internal rechargeable AA NiMH batteries
- Auto Power OFF
- Audible tone for start and end of test
- Rugged molded IP53 case with locking latches and gasket in cover.
- Power Switch incorporates LED indication of battery charge status.
- Low battery indication. Instrument displays LOW BATTERY if test is started when batteries are low.
- Flash upload capability.

### 3.3. INSIDE COVER LABEL

The inside cover label provides information such as safety rating, VT/PT and CT measurement ranges and connection types, battery specifications, a Display Legend for the Main screen and Power Switch LED indicator definitions.




Figure 3

### 3.4. CONTROL FEATURES



Figure 4

**1 IP53 Rated Case:** Rugged molded IP53 case with locking latches and gasket in cover to ensure tight seal when cover is closed.




Figure 5

<p><b>2</b></p>	<p><b>Display:</b> The LCD is 5 x 8 character resolution with 4 lines, each allowing 20 characters (4 x 20 character resolution). The LCD functions as the user interface (UI) to the instrument.</p> <p><b>Backlight:</b> To conserve power, the backlight is OFF when the instrument is turned on and powered up. Enable the backlight by pressing any button. It will turn OFF automatically if after 3 minutes no buttons have been pressed.</p> <p><b>Audible Tone:</b> A single audible tone (beep) will sound when the instrument is turned on, is at the start of a test, is at the end of a test and if an error occurs. <b>NOTE:</b> The audible tone cannot be disabled.</p>
<p><b>3</b></p>	<p><b>USB (Type-C) Connection:</b> Allows connection to the instrument direct to a PC running the DTR Transfer application software. The connection can also be used to charge the batteries from the supplied wall charger or a USB-C port on a PC.</p> <p><b>NOTE:</b> All types of testing are disabled if only the USB-C is connected. Even when the batteries are fully charged. To run a test remotely while the USB-C is present the supplied 12 VDC AC power adapter must also be connected. Tests can be run in real time from the DTR Transfer application software if the instrument is being powered by a 12 Vdc AC power adapter.</p>
<p><b>4</b></p>	<p><b>Measurement Signal Output (H) 5-pin Connector:</b> The H leads will connect at this point for the injection of the test signal. A 30 V(VT) or 5 V(CT) sine wave at a fixed frequency (64 Hz) is injected into the equipment under test (EUT). Voltage (VT/PT) or Current (CT) test is configured prior to performing the tests.</p>

5	<p><b>Measurement Input (X) 3-pin Connector:</b> The X leads will connect at this point which is where the signal from the primary side of the transformer is returned to be measured and compared to the signal being sent.</p>
6	<p><b>12 V<sub>dc</sub> Input Connector:</b> Used to charge batteries and power the instrument when batteries are depleted via an external AC power adapter with barrel connector.</p>
7	<p><b>Power Button:</b> A momentary contact switch that turns the instrument <b>ON (wake)</b> or <b>OFF (sleep)</b>.      To turn instrument ON press Power button  for &gt;2 s.      To turn instrument OFF press Power button  for &gt;2 s.</p> <p><b>NOTE:</b> The <b>red LED</b> embedded in the power button indicates <b>battery charge mode</b> and does not indicate instrument ON/OFF status.</p> <p><b>NOTE:</b> When the instrument is powered <b>OFF</b>, there is still minimal battery usage as the instrument always remains in sleep mode.</p> <p><b>Red LED Indications in Power Button:</b></p> <ul style="list-style-type: none"> <li>- <b>LED Solid:</b> Batteries are charging.</li> <li>- <b>1 s Blinking:</b> There is a problem with the battery charger.</li> <li>- <b>OFF:</b> Batteries are charged.</li> <li>- <b>Flashing Rapidly:</b> Battery(s) missing or one or more are installed reversed.</li> </ul> <p><b>Low Battery Indication:</b> LOW BATTERY will display if a test is run when batteries are too low to complete test.</p>
8	<p><b>Enter  Button:</b> The large enter button allows you to easily navigate through the menu system. It allows the selection and display of choices one level below (if there is a level) in the program flow.</p>
9	<p><b>Navigation Buttons:</b> These large buttons allow you to easily navigate through the User Interface (UI) menu system.</p> <p><b>Left and Right:</b> Pressing the  or  button will navigate left or right through the menu system. The Left and Right buttons are also used to select the next and previous items within a selected group, to display or change values for certain fields like date and time, or for choosing options like YES or NO for example in Nameplate Setup (YES to Enable or NO to Disable Nameplate).</p> <p><b>Up and Down:</b> Pressing the  or  button will navigate up or down through the menu system between the Test, Information, Configuration and Memory Recall screens. The up and down buttons are also used in certain screens to cycle through options or set increments and other values.</p> <p><b>Return (ESC) Command:</b> Pressing and releasing the  and  buttons simultaneously functions as a return (ESC) command returning up one level (if there is a level) in the UI flow. This (ESC) command does not work while on a Test Result screen, Error Message screen or Test Canceled screen. To exit these screens, press the Enter  button.</p> <p>Performing the return (ESC) command ( ) multiple times: results in returning to the Top Level Menu.</p>
10	<p><b>Test Button:</b> The large test button allows for you to easily press to start or stop a test. <b>NOTE:</b> To initiate a test, the instrument must be on a Test screen or a Test Result screen.</p>

Table 2

### 3.5. CABLE IDENTIFICATION

The Primary (H) cable has a 5-pin connector and the Secondary (X) cable has a 3-pin connector. Due to their different pin configurations, the cables cannot be incorrectly inserted into the DTR® 8511 terminals.

**NOTE:** Even though the cables cannot be incorrectly inserted into the DTR® 8511 terminals, the cables can be incorrectly connected to the transformer.

#### 3.5.1. Primary (H) Cable




Figure 6

#### 3.5.2. Secondary (X) Cable




Figure 7

## 4. SPECIFICATIONS

### 4.1. REFERENCE CONDITIONS

Parameter	Reference Conditions
Ambient Temperature	23 ± -13 °C
Relative Humidity	10 to 85 % RH @ 35 °C
Current	No DC component
PT/VT Mode	Output current ≤150 mA
CT Mode	Output current ≤50 mA
Magnetic Field	0 A/m
Electric Field	0 V/m

Table 3

### 4.2. ELECTRICAL SPECIFICATIONS

The following tables define the DTR® 8511 basic operational electrical specifications.

Range	VT 0.8:1 to 8000:1 CT 0.8:1 to 1000:1
Number of Inputs	1
Test Voltage Range	30 V @ 64 Hz
Test Current	(0 to 2) A @ 64 Hz
Measurement Method	In accordance with IEEE Std. C57.12.90™
Communication	USB Type-A to Type-C USB 2.1
Memory	16 MB
Primary Power Supply (charging only)	USB Type-C w/ power adapter or PC
AC Power Supply (supplied)	12 V <sub>DC</sub> 4.3 A
IP Rating	IP53 cover closed

Table 4

#### Ratio Specifications (VT/PT)

Ratio Range	Test Voltage	Accuracy
0.8000 to 9.9999	30 V <sub>AC</sub>	0.2 %
10.000 to 999.99	30 V <sub>AC</sub>	0.1 %
1000.0 to 4999.9	30 V <sub>AC</sub>	0.2 %
5000 to 8000	30 V <sub>AC</sub>	0.25 %

Table 5

#### Ratio Specifications (CT)

Ratio Range	Test Current	Accuracy
0.8 to 1000	(0 to 2000) mA	0.5 %

Table 6

**Current Specifications @ 64 Hz**

Test Current	Accuracy
0 to 2000 mA	+/- (2 % of Reading + 2 mA)

**Table 7**

**For Ratios within (0.8 to 8000)**

Quantity	Label	Unit	Measurement Range
Excitation Frequency	F	Hz	64 Hz

**Table 8**

**Resolution**

See § 6.2.4.

**Influences**

Influence Quantity	Influence Range	Influenced Quantity	Influences		
			MIN	Typical	MAX
Temperature	-10 to +50 °C 14 to 122 °F	I	-	-	0.3 %/10 °C+ 1 D
		Time	-	-	20 ppm / °C 68 ppm / °F
Relative Humidity	10 to 85 % HR	I	-	-	1 % + 2 D
Power Supply	-	I	-	-	0.1 % + 2 D
AC 50/60 Hz Common Mode Rejection	0 to 1000 V <sub>Ac</sub>	I	140 dB	0.5 dB	1 dB
Frequency	64 Hz	I	-	-	-

**Table 9**

**4.3. MECHANICAL SPECIFICATIONS**

**Dimensions:** 251 x 343 x 152 mm

**Mass:** approximately 3.4 kg

**Leads:** 4.6 m with large color-coded industrial alligator clips in carrying bag.

**Drop:** IEC 60068-2-32 - Falls: 1 m in the most severe position without permanent mechanical damage and functional deterioration.

**Operating Position:** Horizontal

**Vibration:** Sinusoidal vibration testing, IEC 60068-2-6

**Shock:** IEC 60068-2-27

**Enclosure:** Rigid molded IP53 (cover closed), locking latches and gasket in cover.

**Index of Protection:** Provided by enclosures: IEC 60529

## 4.4. ENVIRONMENTAL SPECIFICATIONS

### 4.4.1. Temperature and Relative Humidity

1	<b>Reference Temperature:</b> 20 to 26 °C from 45 to 75 % RH
2	<b>Operating Temperature:</b> -10 to 42.5 °C from 10 to 85 % RH -10 to 50 °C from 10 to 75 % RH
3	<b>Storage Temperature:</b> -20 to 35 °C from 0 to 95 % RH -20 to 60 °C from 0 to 75 % RH




Figure 8

Indoor or Outdoor use, in dry locations only.

**Altitude:** Operation: sea level to 2 000 m  
Storage: sea level to 10 000 m

**Degree of Pollution:** The instrument conforms to Pollution Degree 2 as described in IEC 60947-1.

## 4.5. SAFETY SPECIFICATIONS

Electrical Safety



The DTR® 8511 complies with safety rating IEC/EN 61010-2-030, is CE approved and double insulated.

## 4.6. ELECTROMAGNETIC COMPATIBILITY

Emissions and Immunity in an industrial setting compliant with IEC/EN 61326-1.

# 5. DISPLAY FUNCTIONS

## 5.1. THE MENU SYSTEM

The User Interface (UI) menu system is designed in a tiered manor with a Top Level Menu consisting of the Test, Information, Configuration and Memory Recall menus. The UI also consists of 2nd Level Menus and 3rd Level Menu (options). A menu can also be referred to as a screen.

Reference flow charts (see Figures 74-77) for further details on the layout of the Test screen, Information screen, Configuration screen and Memory Recall screen.




Figure 9

### 5.1.1. Title Screen

The Title screen is only visible at power up of the instrument. It is from here that you will enter the menu system.

The Title screen remains displayed until either the Enter , or any of the navigation buttons ( , , , or  ) are pressed to proceed to the Test screen, or two minutes have lapsed with no button presses at which time the instrument will automatically proceed to the Test screen.

The Title screen displays the Company Name, Date and Time, and Battery Charge Status in % (see Figure 10).

The Title screen will not appear again until the next power up of the instrument.

The Title screen Name defaults to AEMC INSTRUMENTS. The first line of the Title screen can be custom configured at the factory per request made at time of purchase, to display a custom name up to 20 ACSII characters. The user cannot configure the Name on the Title screen.



**NOTE:** The battery charge status will not display on the Title screen while the battery is charging (see Figure 11).




Figure 10




Figure 11

### 5.1.2. Navigating the Menu System

The user can navigate around the UI menu system by pressing the Up , Down , Left , or Right  navigation buttons.

- **Vertical Navigation:** Pressing the  or , button will navigate up or down a menu level. For example it allows to navigate between the Test, Information, Configuration and Memory Recall screens (see Figure 9). These buttons are also used to select the next and previous items within a selected group and to display or change values for certain fields like date and time.
- **Horizontal Navigation:** Pressing the  or  button will navigate left or right within a menu level. It allows to select the next and previous items within a selected group, to display or change values for certain fields like date and time, or for choosing options like *YES to Enable* or *NO to Disable* Nameplate in Nameplate Setup.
- **Return (ESC) Command:** Pressing and releasing the  and  buttons simultaneously functions as a return (ESC) command to return up one level (if there is a level) in the UI flow. **NOTE:** To exit a Test Result screen, an Error Message screen or a Test Canceled screen you must press .
- **Performing the return (ESC) command (   ) multiple times:** Ultimately results in returning to the Top Level Menu (VT/PT Ratio Mode test screen).
- **Enter  Button:**
  - Pressing the  button from the Title screen allows you to navigate to the Top Level Menu (Test screen).
  - Pressing  allows you to cycle through options such as language types, date formats or filter types and to make selections such as enabling or disabling a nameplate.
  - Pressing  also allows you to exit from Test Result screens, Error Message screens and Test Canceled screens.
- **Test Button** : Pressing the **TEST** button will start or stop (cancel) a test.
- **Power Button  :** **Red LED** Indications located within power button.
  - If LED is:
    - **Solid:** Batteries are charging
    - **1 s Blinking:** There is a problem with the battery charging
    - **OFF:** Batteries are partially or fully charged
    - **Flashing rapidly:** Battery missing or installed reversed
- **Low Battery Indication:** LOW BATTERY will display if test is run when batteries are low.

### 5.1.3. Top Level Menu

The user can continuously cycle through the Top Level Menu by pressing either the  or  navigation button.

- Test screen
- Information screen
- Configuration screen
- Memory Recall screen




Figure 12

#### 5.1.3.1. Test Screen

---

 **NOTE:** Instrument must be on a Test screen or a Test Result screen to start a test.

---

Each Test screen displays:

- Test Type (VT/PT, CT or Continuity)
- Date and time set in the instrument
- Storage Mode [Auto SAVE, NO SAVE or MAN (manual)]
- [(LOW) if battery is too low to run a test]

The VT/PT and CT Test screens also display:

- Present Nameplate values (if Nameplate enabled)
- Filter Type [(Fast (FAST), Normal (NORM) or Slow (SLOW))]

**NOTE:** For VT/PT and CT Test screens, if Nameplate is not enabled then the primary (P) and secondary (S) values will not be displayed.

From the Title screen press  or  to navigate to the Top Level Menu.

Use  or  to navigate horizontally and  or  to navigate vertically through the menu system.

**5.1.3.1.1. VT/PT Ratio Mode (Nameplate Enabled - Deviation Available)**

Allows the selection of VT/PT test type.

- Navigate to the VT/PT Ratio Mode Test screen.




Figure 13

- Press  to **Start** test. The TEST IN PROGRESS screen will display and a single audible tone (BEEP) will sound signaling a test is in progress.




Figure 14

- Press  again to **Cancel** test. The TEST CANCELED screen will display and a double audible tone (BEEP) will sound signaling test canceled.




Figure 15

- Press  exit screen and return to Top Level Menu.

**<OR IF TEST COMPLETES>**

- The TEST RESULT screen will display. In this example Storage Mode **NO SAVE** was selected.




Figure 16

- Press  to return to Top Level Menu.

**<OR IF AUTO SAVE IS SELECTED>**




Figure 17

<OR IF MANUAL MODE IS SELECTED>

- The MANUAL MODE OPTION SAVE TEST? screen will display.




Figure 18

- To select **NO**: Press to return to Top Level Menu.
- To select **YES**: Press to continue with Saving Data. If memory is available, the SELECT MEMORY screen will display AVAILABLE showing an available memory location.




Figure 19

- Press to complete Saving Data operation OR change memory OBJ and TST locations.
- The cursor will blink under the OBJ digit. To change the suggested memory location use or to select digit and or to edit digit.
- Next use to navigate to TST digit. Use or to select digit and or to edit digit.

---

**NOTE:** If the storage memory OBJ# and TST# combination has already been used, NOT AVAILABLE will display.

---

- When ready, press to complete Saving Data operation.

---

**NOTE:** Expect short delay as data is being saved to EEPROM (electrically erasable programmable read-only memory).

---

- The SAVED screen will display.




Figure 20

- Press to return to Top Level Menu.

**5.1.3.1.2. CT Ratio Mode**

Allows the selection of CT Test Type.

- Navigate to the CT Ratio Mode Test screen.




Figure 21

- Press  to **Start** test. The TEST IN PROGRESS screen will display and a single audible tone (BEEP) will sound signaling a test is in progress.




Figure 22

- Press  to **Cancel** test. The TEST CANCELED screen will display and a double audible tone (BEEP) will sound signaling the test has been canceled.




Figure 23

- Press  to exit screen and return to Top Level Menu.

**<OR IF TEST COMPLETES>**

- The TEST RESULT screen will display. In this example Storage Mode **NO SAVE** was selected.




Figure 24

- Press  to return to Top Level Menu.

**<OR IF AUTO SAVE IS SELECTED>**




Figure 25

**<OR IF MANUAL SAVE IS SELECTED>**

- The MANUAL MODE OPTION SAVE TEST? screen will display.




Figure 26

- To select **NO**: Press to return to Top Level Menu.
- To select **YES**: Press to continue with Saving Data. If memory is available, the SELECT MEMORY screen will display AVAILABLE showing an available memory location.




Figure 27

- Press to complete Saving Data operation OR change memory OBJ and TST locations.
- The cursor will blink under the OBJ digit. To change the suggested memory location use or to select digit and or to edit digit.
- Next use to navigate to TST digit. Use or to select digit and or to edit digit.

---

**NOTE:** If the storage memory OBJ# and TST# combination has already been used, NOT AVAILABLE will display.

---

- When ready, press to complete Saving Data operation.

---

**NOTE:** Expect short delay as data is being saved to EEPROM (electrically erasable programmable read-only memory).

---

- The SAVED screen will display.




Figure 28

- Press to return to Top Level Menu.

### 5.1.3.1.3. Continuity Test

Allows the selection of Continuity Test Type.

- Navigate to the Continuity Test screen.




Figure 29

- Press  to **Start**.




Figure 30

- Press  again to **Cancel**.



Figure 31



**NOTE:** A double audible tone (BEEP) will sound signaling that the test has been canceled.

- Press  to return to Top Level Menu.

**<OR IF TEST COMPLETES>**

- The CONTINUITY RESULT screen will display. In this example Storage Mode **NO SAVE** was selected.




Figure 32

- Press  to return to Top Level Menu.

**<OR if AUTO SAVE IS SELECTED>**




Figure 33

**<OR if MANUAL SAVE IS SELECTED>**

- The MANUAL MODE OPTION SAVE TEST? screen will display.




Figure 34

- To select **NO**: Press  to display the Test Result screen then press  to return to Top Level Menu (Test screen).
- To select **YES**: Press  to continue with Saving Data. If memory is available, the SELECT MEMORY screen will display AVAILABLE showing an available memory location.




Figure 35

- Press to complete Saving Data operation OR change memory OBJ and TST locations.




Figure 36

- The cursor will blink under the OBJ digit. To change the suggested memory location use or to select digit and or to edit digit.
- Next use to navigate to TST digit. Use or to select digit and or to edit digit.

**NOTE:** If the storage memory OBJ# and TST# combination has already been used, NOT AVAILABLE will display.

- When ready, press to complete Saving Data operation.

**NOTE:** Expect short delay as data is being saved to EEPROM (electrically erasable programmable read-only memory).

- The SAVED screen will display.




Figure 37

- Press to run next test.
- Press to exit screen back to Top Level Menu.

### 5.1.3.2. Information Screen

Displays information about the instrument. Use and to cycle through information options.

- Instrument ID
- Battery Status
- Date and Time




Figure 38

#### 5.1.3.2.1. Instrument ID

Provides Model Name, Serial Number and Firmware Revision.




Figure 39

**5.1.3.2.2. Battery Status - Normal Mode**

Provides Battery percent charged (0 % to 100 %) and Charging status (YES or NO).




Figure 40

OR




Figure 41

OR

**5.1.3.2.3. Date/Time**

Provides the Date-Format and Time-Format.




Figure 42

**5.1.3.3. Configuration Screen**

Allows to set various configuration parameters of the instrument. Use and to cycle through configuration parameter options.

- Select Language
- Set Clock
- Erase Memory
- Select Filter
- Select Storage Mode
- Result Delay Time
- Nameplate Setup




Figure 43

Configuration Parameter and Value Options													
Parameter	Value Options												
Select Language	English, Francais, Deutsch, Italiano, Espanol, Portugues												
Set Clock	<p>Date Format Options: MM/DD/YY, DD/MM/YY, YY/MM/DD</p> <p>Time Format Options: 24 HOUR, 12 HOUR</p> <p>AM or PM: Displays only if Time Format is set to 12 HOUR.</p> <p>At SET DATE screen press , use  or  to set date values and  or  to navigate between date fields.</p> <p>The date is always entered into YYYY/MM/DD format.</p> <p>Press  to accept.</p> <p>At SET TIME screen press , use  or  to set values and use  or  to navigate between fields.</p> <p>Press  to accept. This returns you to the default SET DATE 06/15/23 screen which will not reflect the modified date. All other screens will reflect new date and new date format.</p>												
Select Filter	Normal, Slow, Fast												
Select Storage Mode	Manual Save, Auto Save, No Save												
Result Delay Time	Press  to modify increment: (01, 02, 03, 04, 05, 06, 07, 08, 09, 10) min.												
Nameplate Setup	<p>Enable (Yes or No)</p> <p>If Nameplate is enabled Deviation is available and will display as a D with a % value.</p> <p>If Nameplate is not enabled, Deviation is not available and will display as N/A.</p>												
Nameplate Values	<table border="0"> <tr> <td>#1: 19920:7200</td> <td>#7: 7200:2160</td> </tr> <tr> <td>#2: 19920:4800</td> <td>#8: 7200:120</td> </tr> <tr> <td>#3: 19920:2400</td> <td>#9: 2400:120</td> </tr> <tr> <td>#4: 19920:2160</td> <td>#10: 2160:120</td> </tr> <tr> <td>#5: 19920:120</td> <td>Custom - Allows to create custom nameplates</td> </tr> <tr> <td>#6: 7200:2400</td> <td></td> </tr> </table>	#1: 19920:7200	#7: 7200:2160	#2: 19920:4800	#8: 7200:120	#3: 19920:2400	#9: 2400:120	#4: 19920:2160	#10: 2160:120	#5: 19920:120	Custom - Allows to create custom nameplates	#6: 7200:2400	
#1: 19920:7200	#7: 7200:2160												
#2: 19920:4800	#8: 7200:120												
#3: 19920:2400	#9: 2400:120												
#4: 19920:2160	#10: 2160:120												
#5: 19920:120	Custom - Allows to create custom nameplates												
#6: 7200:2400													

Table 10

### 5.1.3.3.1. Select Language

Language options are:

- English (Default)
- Italiano
- Français
- Español
- Deutsch
- Português

- Use , ,  or  to navigate to the Configuration Language top screen.




Figure 44

- Continuously press  to cycle through other language options. Stopping on desired language will select that language. The instrument will immediately change over to selected language.

**NOTE:** Use  or  to navigate to next or previous configuration parameter or use return (ESC) command ( ) to return to Top Level Menu.

### 5.1.3.3.2. Set Clock

Allows user to first select date and time formats, then proceed to set the date and time. Date/Time cannot be set when a test is active.

- Use , ,  or  to navigate to the Configuration Set Clock screen.




Figure 45

- Continuously press  to cycle through the three Date Format options. Stopping on desired date format will select that format.




Figure 46




Figure 47




Figure 48

- Press  to navigate to the Configuration Time Format screen.
- Continuously press  to toggle between 24 HOUR and 12 HOUR options. Stopping on desired time format will select that format. Otherwise, Time Format will default to 12 HOUR.




Figure 49




Figure 50

- When ready, press  to navigate to the Configuration Set Date default screen.




Figure 51

- Press  to activate the Set Date entry screen. Regardless of which date format you previously selected, the date on this screen is entered into YYYY/MM/DD format.




Figure 52

- Use  and  to move between the year, month and day fields. The cursor will blink beneath the selected digit. Use  and  to edit the digit.
- When ready press  to accept date settings.
- The program accepts the date settings and returns you to the Configuration Set Date (**06/15/23**) default screen. The date on this screen (see Figure 51) is always 06/15/23. The newly set date will not show on this screen, but will be reflected on all other dated screens, such as the Title screen and Test screens.
- When ready, press  to navigate to the Configuration Set Time screen.




Figure 53

- Press  to activate the Time entry screen. The time is entered into HH:MM:SS format.




Figure 54

- Use  and  to move between the hour, minutes and seconds fields. The cursor will blink beneath the selected digit. Use  and  to edit the digit.
- When ready, press  to accept time settings.
- The program accepts the time settings and returns you to the Configuration Set Time screen. The newly set time will be reflected on this screen.

---

 **NOTE:** Use  or  to navigate to next or previous configuration parameter or use return (ESC) command () to return to Top Level Menu. 

---

### 5.1.3.3.3. Erase Memory

Allows deletion of all the stored measurement records.

- Use , ,  or  to navigate to the Configuration Erase Memory top screen.




Figure 55

- Press  to navigate to the Erase Memory Continue? screen.




Figure 56

- To select **YES**: Press  and the ERASING MEMORY PLEASE WAIT screen will display to confirm memory is being erased.




Figure 57

- To select **NO**: Press  to return to the Configuration Erase Memory top screen.



**NOTE:** When the Erase Memory operation completes, the program automatically returns to the Erase Memory Top Level Menu (Figure 55).



**NOTE:** Use  or  to navigate to next or previous configuration parameter or use return (ESC) command ( ) to return to Top Level Menu.

### 5.1.3.3.4. Select Filter

The selectable filter speed on the DTR® 8511 (SLOW, NORMAL and FAST) affects the number of samples acquired during a measurement cycle, but only results in a modest change in total reading time.

The **SLOW** filter collects the highest number of samples, followed by the **NORMAL** filter and then the **FAST** filter, which collects the smallest number of samples.

Despite this variation, the actual measurement time between modes is minimal:

The **SLOW** filter typically completes a reading just (1 to 2) seconds faster than the **NORMAL**.

The **NORMAL** filter typically completes a reading just (1 to 2) seconds faster than the **FAST** filter.

This modest time increase is due to the higher sample count required by slower filters, which extends the acquisition period before the instrument reaches its stability threshold and finalizes the reading.

- Use , ,  or  to navigate to the Configuration Filter top screen.
- Continuously press  to cycle through the Filter screens. Stopping on desired Filter screen will select that filter.




Figure 58




Figure 59




Figure 60

---

 **NOTE:** Use  or  to navigate to next or previous configuration parameter or use return (ESC) command ( ) to return to Top Level Menu.

---

#### 5.1.3.3.5. Select Storage Mode:

Allows the selection of the data storage mode. The factory default is Manual Save.

There are three options for the storage of tests defined below.

- **MANUAL:** The user is given the choice to save the results. Defaults to next available location and is user selectable.
- **AUTO SAVE:** Stores the test results in the next available memory location.
- **NO SAVE:** Does not store the results.

- Use , ,  or  to navigate to the Configuration Storage Mode top screen.
- Continuously press  to cycle through the three Storage Mode screens. Stopping on desired Storage Mode screen will select that mode.




Figure 61




Figure 62




Figure 63

---

 **NOTE:** Use  or  to navigate to next or previous configuration parameter or use return (ESC) command ( ) to return to Top Level Menu.

---

#### 5.1.3.3.6. Result Delay Time

Allows you to set the amount of time in minutes that a displayed result is shown before returning to the Top Level Menu. Display time is adjustable between (1 to 10) min.

- Use , ,  or  to navigate to the Configuration Result Delay top screen.
- Continuously press  to cycle through increments (1, 2, 3, 4, 5, 6, 7, 8, 9 and 10) min. Stopping on desired result delay time increment selects that increment.




Figure 64

---

 **NOTE:** Use  or  to navigate to next or previous configuration parameter or use return (ESC) command ( ) to return to Top Level Menu.

---

#### 5.1.3.3.7. Setup Nameplate

Allows selection and editing of present Nameplate voltages or ratios. Predefined ratios can only be edited through DataView®. Factory default is Disable. Nameplate must be enabled for Deviation to be available.

---

 **NOTE:** If Nameplate is not enabled then the Primary (P) and Secondary (S) values will not be displayed.

---

- Use , ,  or  to navigate to the Configuration Nameplate Setup screen.




Figure 65

- Press  to navigate to Nameplate Enable screen.




Figure 66

- To not enable Nameplate (**NO**): Press  to return to the Configuration Nameplate Setup screen. Note that Deviation will not be available.
- To enable Nameplate (**YES**): Press  and the NAMEPLATE SELECT screen will display. This will allow you to choose between the List or Custom screens and Deviation will be available.




Figure 67

The List option will allow you to select from 10 set nameplate values plus one set custom option (see Figure 68).

- Press to select the List option.
- Use and to cycle through set nameplates (1 through 10) plus one set custom nameplate.
- Stop on desired nameplate option and press to accept and return to the Configuration Nameplate Setup screen.



Figure 68

- The Custom option will allow you to set a custom ratio. From the Nameplate Select screen (see Figure 69) press to select the **Custom** option.
- **Setting Primary and Secondary custom ratio values:** The cursor will blink beneath the first Primary digit (see Figure 69). Use and to edit digit. Then use or to cycle through fields and set values for remaining Primary and Secondary digit fields.




Figure 69

- When ready, press to accept settings and return to the Configuration Nameplate Setup screen (see Figure 65).

---

**NOTE:** Use or to navigate to next or previous configuration parameter or use return (ESC) command ( ) to return to Top Level Menu.

---

#### 5.1.3.4. Memory Recall Screen

Allows stored data to be searched and displayed. Displays the amount, in percentage, of used memory slots. The actual used memory slot percentage would be shown where [ 0 - 100 % ] is located in the below example (Figure 70).




Figure 70

- Press to proceed to the Memory Recall OBJ#/TST# search screen.
- Use and to cycle through OBJ # and TST # fields. Stop on desired field and use and to set desired OBJ#

and TST# values for search.

- If saved data is found for search parameters, DATA FOUND will display.




Figure 71



**NOTE:** If data is not available for the entered OBJ# and TST# search parameters, NO DATA FOUND will display.

- If **DATA FOUND**, when ready press to display available data.
- Use or to scroll line by line through recalled data.




Figure 72




Figure 73

- Press to return to the Memory Recall OBJ#/TST# search screen.



**NOTE:** Use return (ESC) command ( ) to return to Memory Recall top screen or use return (ESC) command ( ) twice to return to Top Level Menu.

#### 5.1.4. Menu System Flow Charts

To use the instrument efficiently, it is important to understand the program flow. The following charts (Figures 74-77) highlight the flow of the Test, Information, Configuration and Memory Recall top level, 2nd Level and 3rd Level Menu (options).

5.1.4.1. Test Screen




Figure 74

5.1.4.2. Information Screen



Figure 75

5.1.4.3. Configuration Screen




Figure 76-a




Figure 76-b

5.1.4.4. Memory Recall Screen




Figure 77

5.2. TEST RESULT SCREENS

The display of test results can vary depending on the test Type-And the save mode. Ratio results can be saved.

**i** NOTE: Press Enter  to exit a Test Result screen.

**i** NOTE: If Nameplate is not enabled, Deviation (D) will show N/A in place of a percent value.

No Save Mode




Figure 78

**No Save Mode - No Deviation (Nameplate Disabled)**

```
TEST RESULT
R : 1 . 0 0 0 0 : 1
D : N / A C : 2 m A
NOT SAVED
```

Figure 79

**Auto Save Mode**

```
TEST RESULT
R : 1 . 0 0 0 0 : 1
D : 1 0 . 1 % C : 2 m A
SAVED OBJ # 0 1 TST # 0 1
```

Figure 80

**Auto Save Mode - No Deviation (Nameplate Disabled)**

```
TEST RESULT
R : 1 . 0 0 0 0 : 1
D : N / A C : 2 m A
SAVED OBJ # 0 1 TST # 0 1
```

Figure 81

**Manual Save Mode**

```
MANUAL MODE OPTION
SAVE TEST?
R : 2 . 6 7 6 3 : 1 D : 0 0 . 1 %
< YES NO >
```

Figure 82

**Manual Save Mode - No Deviation (Nameplate Disabled)**








```
MANUAL MODE OPTION
SAVE TEST?
R : 1 . 0 0 0 0 : 1 D : N / A
< YES NO >
```

Figure 83

### 5.3. ERROR MESSAGES



**NOTE:** Press Enter  to exit an Error Message screen.

Error Screen Message	Reason for Error	Resolution
 <p style="text-align: center;"><i>Figure 84</i></p>	<p><b>LOW X SIGNAL</b> Typically due to X leads issue. Displays if the X lead is open. Displays if measured ratio is 20 % over max limits.</p>	<p>Verify that cables are not damaged or incorrectly connected to transformer.</p>
 <p style="text-align: center;"><i>Figure 85</i></p>	<p><b>LOW H SIGNAL</b> Displays if H voltage is lower than expected limit. Can also indicate that the X and H leads are reversed at transformer.</p>	<p>Verify that cables are not damaged or incorrectly connected to transformer.</p>
 <p style="text-align: center;"><i>Figure 86</i></p>	<p><b>HIGH CURRENT</b> Displays if current is too high during test measuring transformer.</p>	<p>Verify that cables are not damaged or incorrectly connected to transformer.</p>
 <p style="text-align: center;"><i>Figure 87</i></p>	<p><b>X AND H REVERSED</b> Displays if the X and H leads are connected reversed at transformer. Can also indicate H voltage is lower than expected limit.</p>	<p>Verify that cables are not damaged or incorrectly connected to transformer.</p>
 <p style="text-align: center;"><i>Figure 88</i></p>	<p><b>CONTINUITY ADC FAULT</b> Displays if ADC failed to complete conversion.</p>	<p>HW failure return instrument for repair.</p>
 <p style="text-align: center;"><i>Figure 89</i></p>	<p><b>SAVE DATA FAILURE</b> Displays if unable to save test data due to an EEPROM issue.</p>	<p>HW failure return instrument for repair.</p>
 <p style="text-align: center;"><i>Figure 90</i></p>	<p><b>LOW BATTERY</b> Displays if battery is too low to run test. Under this condition the test will not run.</p>	<p>Charge the batteries. See § 9.2.2</p>
 <p style="text-align: center;"><i>Figure 91</i></p>	<p><b>VERY LOW BATT &lt; 6V1 TEST CANCELED</b> Displays if there is an over current situation or if batteries are too low to execute test. This condition may be due to improper cabling or test setup.</p>	<p>Verify cabling is correct and retry. If condition persists, charge the batteries. See § 9.2.2</p>

Error Screen Message	Reason for Error	Resolution
<pre> VT / PT RATIO MODE * * ERROR DETECTED * * NOR CHECK FAILED </pre> <p>Figure 92</p>	<p><b>NOR CHECK FAILED</b> Indicates that EEPROM is faulty or incompatible.</p>	<p>HW failure return instrument for repair.</p>
<pre> ← VT / PT RATIO MODE → 10 \ 10 \ 23 10 : 10 : 10 AM P : 019920 S : 007200 NO SAVE , FAST , LOW </pre> <p>Figure 93</p>	<p><b>NO SAVE, FAST, LOW</b> LOW = Low Battery WARNING.</p>	<p>Charge the batteries. See § 9.2.2</p>
<pre> * * ERROR DETECTED * * BATT CHARGER FAULT REMOVE USB AND 12Vdc </pre> <p>Figure 94</p>	<p><b>BATT CHARGER FAULT</b> Displays if battery charger detected a fault.</p>	<p>Restart if error persist. Check that batteries are inserted correctly. If batteries are inserted correctly, batteries should be replaced.</p>
<pre> * * ERROR DETECTED * * HOLD POWER BUTTON 2s THEN RESTART SYSTEM </pre> <p>Figure 95</p>	<p><b>REMOVE USB AND 12 Vdc</b> Displays if battery charger detected a fault.</p> <p><b>RESTART SYSTEM</b> Displays in rare case of a battery charging failure.</p>	<p><b>Restart charger hardware:</b> Remove all external power. Then hold down power button for &gt;2 s. After instrument enters sleep-mode, wake-up with power button press of &gt;2 s. If this is not successful contact the Technical Support.</p>

Table 11

## 5.4. BATTERY WARNING MESSAGES

Warning Screen Message	Reason for Warning	Resolution
<pre> *** WARNING *** USB - C OR 12V POWER IS REQUIRED SYSTEM HALTED </pre> <p>Figure 96</p>	<p>Warning will display if battery voltage has dropped below 6.0 V and user attempted to turn instrument ON without first connecting external power. <b>NOTE:</b> An instrument powered off for an extended period of time could be subject to a voltage drop.</p>	<p>User must connect external power via either the USB-C cable or 12 V<sub>DC</sub> AC power adapter. Instrument will then proceed to <b>System Charging</b> warning screen (Figure 97).</p>
<pre> *** WARNING *** BATTERY VERY LOW SYSTEM CHARGING PLEASE WAIT </pre> <p>Figure 97</p>	<p>This warning screen will display when external power is present and instrument wakes. At this point the instrument halts normal operation and tries to recover the batteries by applying a trickle charge.</p>	<p>User should WAIT and allow system to charge. When the battery voltage returns to a level that allows for normal charging operations, the instrument then returns to normal charging operational mode.</p>

**NOTE:**

. . .WARNING. . . will flash if frequency is at a rate of 1 Hz.

Warning Screen Message	Reason for Warning	Resolution
------------------------	--------------------	------------

**If Instrument does not return to normal charging mode within 5 minutes:**  
 The batteries require replacement. External power **must** now be removed and the instrument shut down.

**If Instrument does return to normal charging mode within 5 minutes:**  
 Instrument will return to Top Level VT/PT Test screen.  
 It is strongly recommended that the power remains present for the full charge cycle to complete before being unplugged. The charge indicator (power button backlight) turns off indicating the charge cycle has completed. This could take up to 10 hours.

Table 12

## 5.5. BATTERY ERROR MESSAGES

BATTERY ERRORS		
Error Condition	Error Screen Message	Reason for Error
Battery Charger Fault	BATT CHARGER FAULT	Battery charger detected a fault
Battery Fault	LOW BATTERY FAULT	Batteries are low and not charging
	NEEDS REPLACEMENT	If charger is already plugged in
	PLUG IN CHARGER	If charger is not plugged in
	REMOVE USB and 12 Vdc	Battery charger detected a fault. May indicate the orientation of battery insertion is incorrect.

Table 13

A Battery Fault message may come up when batteries are below 6.0 V. You will need to plug in either the 12 V<sub>dc</sub> AC power adapter or USB-C power to get the instrument to turn on.

If the NEEDS REPLACEMENT message shown below is displayed and the instrument is unresponsive:




Figure 98

- Please wait 5 minutes while the instrument tries to charge the batteries.
- After the 5 minute waiting period, unplug power supplies.
- Turn instrument OFF (hold power button down for >2 s).
- Turn instrument ON (hold power button down for >2 s).
- If instrument turns on, continue with step 6, if instrument does not turn on batteries need to be replaced. Contact the Technical Support.
- Plug in 12 V<sub>dc</sub> AC power adapter or USB-C power source.
- Let batteries continue the full charge cycle of 10 h.

**NOTE:** In order for the instrument to accurately track and display the battery charge status, the NiMH batteries used by this instrument must complete the 10 h battery charge cycle.

## 6. OPERATION

### 6.1. DATA MEASUREMENT

#### 6.1.1. Voltage (VT/PT)

- Test voltage is fixed at 30 V @ 64 HZ.

#### 6.1.2. Current (CT)

- Test voltage is fixed at 5 V @ 64 HZ.
- Test current is supplied up to 2 A @ 64 HZ.

#### 6.1.3. Continuity

- Test voltage is 1.2 V<sub>DC</sub>

The Continuity Test function of the DTR® 8511 serves as a useful means of identifying whether the windings of a transformer, Primary (H) or Secondary (X), are open-circuit or closed-circuit.

First, the instrument checks for Primary (H) connections. Even if it is found OPEN, the test continues to check the Secondary (X) connections. If the Primary winding (H) or Secondary winding (X) or both were found to be OPEN, the instrument will display the appropriate message, FAIL. Pressing the TEST button again will start a new Continuity test.

Transformers with winding arrangement multiple, parallel paths (e.g., Delta type) may get a continuity reading of a short even if one of those windings passes the continuity test.

- Continuity checks for the continuity in the cables and transformer winding. It does not check for X and H reversed polarity.
- If the continuity for the Primary connections is within specified limits, the display shows PASS (equivalent to a Closed Switch).
- If the continuity for the Primary connections is outside the specified limits, the display shows FAIL (equivalent to an Open Switch).

### 6.2. MEASURING DATA

#### 6.2.1. Measured Quantities

- Ratio
- Excitation current
- Date/Time of test

#### 6.2.2. Calculated Quantities

Ratio Deviation (displayed if Nameplate is enabled) compares selected nameplate expected ratio values to measured ratio value to determine the percentage of deviation from the expected ratio.

#### 6.2.3. Stored Quantities

At the end of each test the measurement results can be stored. The stored measurement data is:

- Ratio or Continuity
- Excitation current
- Test type
- Date/Time stamp
- Deviation, if Nameplate is enabled
  - Selected Nameplate values
- Continuity results, if selected
  - Primary winding
  - Secondary winding

### 6.2.4. Units and Digits

The following table defines displayed resolution as specified by the defined ranges. The purpose of this table is for **display**, not for measurement.

AVAILABLE RANGES (FOR DISPLAYING)				
	Label	Ratio Range	Units	Resolution
*Ratio	R	0.8000 to 9.9999	Measurement to 1	0.0001
		10.000 to 99.999	Measurement to 1	0.001
		100.00 to 999.99	Measurement to 1	0.01
		1000.0 to 8000.0	Measurement to 1	0.1
Test Current	C	1 to 2000	mA	**1 mA
				***>2 A
Nameplate (P and S)	P / S	V(VT) or A(CT)	1 - 999999: 1 - 999999	1
Deviation	D	%	+/- 0.00 - 9.99	0.01
		%	+/- 10.0 - 99.9	00.1
		%	+/- 100 - 999	****001
Battery	%	0 to 100	%	1 %

**Table 14**

\*Ratios greater than max+10 % and less than max+20 % will show a message Out of Range. Ratios greater than max+20 % will cause an error condition.

\*\*Display shows <1 mA when below 1 mA

\*\*\*Display shows >2 A when above 2000 mA

\*\*\*\*Display shows > % when above 999 %

### 6.2.5. Recorded Data

The instrument stores the acquired data to an internal memory. The DTR Transfer application software can be used to run tests, erase memory, configure tests, configure custom nameplate values, and download and print the recorded data.

### 6.2.6. Buzzer

A single audible tone (beep) will sound when the instrument is turned on, is at the start of a test, is at the end of a test and if an error occurs.

## 6.3. POWER UP INSTRUMENT

The instrument can only go into a deep sleep state to preserve the battery when the 12 Vdc AC power adapter and USB cable are disconnected, and the instrument is running on batteries.

If the instrument is in OFF state (deep sleep state) you must press the power button to wake up the instrument.

- Press and hold power button  for >2 s when on batteries.
- Plug in the USB cable.
- Plug in the 12 Vdc AC power adapter.



**NOTE:** If the batteries are depleted, the instrument will then need to be powered by the USB cable or 12 Vdc AC power adapter.



**NOTE:** If the batteries are insufficiently charged and the instrument is not externally powered:

- When running on batteries only, and the batteries are low, the power button red LED will blink ON for 1 s and OFF for 1 s.
- The instrument cannot be used for testing under these circumstances.
- The batteries must be charged before use (see § 9.2) or an external power source (USB or 12 Vdc AC power adapter must be connected).

To turn the instrument OFF press and hold power button  for >2 s.



**WARNING:** The DTR® 8511 is designed for use on de-energized (dead) transformers ONLY. Make sure the test sample is completely disconnected from AC power and is fully discharged.

## 6.4. RUNNING A TEST FROM THE INSTRUMENT

### 6.4.1. Canceling a Test

Note that a test can be canceled at any time by pressing the **TEST** button during the operation. The BY USER TEST CANCELED screen will display.




Figure 99

Press  to exit a Test Canceled screen.



**NOTE:** The instrument must be on the VT/PT Test screen to start a VT/PT test.

### 6.4.2. VT/PT Test



**WARNING:** It is important to make sure the Primary (H) and Secondary (X) cables are connected properly BEFORE running the test. This is especially true for the high turn-ratio transformers since dangerous high voltage may appear on the DTR® 8511 terminals.

In this section, an example of running a VT/PT Ratio test using the following configuration is shown.

- Batteries fully charged
- No USB connection
- Set Date/Time: 10/10/23 10:10:10 AM
- Set/recall nameplate values: Primary Voltage:19920; Secondary Voltage: 7200



**NOTE:** Nameplate selection is optional and only needs to be enabled to display Deviation.

- Select Type: VT/PT
- Storage Mode: Manual
- Set Filter: Fast




Figure 100

**Typical Connection - Ratio 2.767:1**




Figure 101

**Alternate Connection - Ratio 1.383:1**




Figure 102

**6.4.2.1. VT/PT Test and Saving Screens**

- Connect the Primary (H) and Secondary (X) cables to the appropriate connectors on the DTR® 8511 and the transformer under test (see Figures 101 & 102).
- Press the **TEST** button. The VT/PT test will run the ratio test. The display will appear as shown below.




Figure 103



**NOTE:** During the Ratio test, the instrument will check if X and H are reversed, short (excessive current) before conducting ratio test.

- In this example, if the test has successfully finished, the display will appear as shown below.




Figure 104

- If the X and H are reversed, the instrument will display the below error message and terminate the test.




Figure 105

- If the H lead is open, then the instrument will display the below error message and terminate the test.




Figure 106

- If the X lead is open, then the instrument will display the below error message and terminate the test.




Figure 107

### 6.4.3. CT Test

#### 6.4.3.1. CT Test and Saving Screens

In this section, an example of running a test with the instrument using the following configuration is shown:

- Batteries fully charged
- No USB connection
- Set Date/Time: 10/10/23 10:10:10 AM
- Set/recall nameplate values: Primary Voltage: 200; Secondary Voltage: 5
- Select Type: CT Test
- Storage Mode: Manual
- Set Filter: Fast



**NOTE:** Instrument must be on the CT Test screen to START a CT test.




Figure 108

- Connect the Primary (H) cable to the appropriate connectors on the DTR® 8511 and the transformer under test. Connect the Secondary (X) cable as a loop through the current transformer hole as shown below.




Figure 109

- Press the **TEST** button. The display will appear as shown below.  
During the Ratio test, the instrument will check for X and H reversed polarity, short (excessive current) before conducting Ratio test.




Figure 110

- In this example, if the test has successfully finished, the display will appear as shown below.




Figure 111

- The CT test ramps up the voltage in steps. At the end of the test, it ramps down the voltage.
- There are certain low mass, low ratio CT's for which the DTR® 8511 may not be able to provide correct ratio. The error message will be **HIGH EXCITATION CURRENT**.

As in VT/PT, the CT test may be run as many times as needed by pressing the **TEST** button.

Also as in VT/PT, the measurement records can be saved in Manual or Auto mode.

The instrument retains selection for CT test until the configuration is changed. Powering the instrument down and turning it back on will not change the Test Type.

#### 6.4.4. Continuity Test

In this section, an example of running a Continuity test using the following configuration is shown.

- Batteries fully charged
- No USB connection
- Set Date/Time: 10/10/23 10:10:10 AM
- Select Type: Continuity Test
- Storage Mode: Manual



**NOTE:** Instrument must be on the Continuity Test screen to START a Continuity test.




Figure 112

## 6.5. INSTRUMENT USER INTERFACE (UI)

The instrument indicates measured quantities and status using the 4-line alphanumeric display on the front panel of the instrument. This display, in conjunction with six control buttons, provides the features and functionality that enable the instrument to operate as a standalone device.

Optional control can be attained by using the included DataView® software which interfaces with the instrument through USB. This will allow remote operation with an enhanced interface for configuration, viewing of measurements and running tests remotely.

When the instrument is connected to a 12 V<sub>DC</sub> AC power adapter or USB, the display is ON. Sleep mode will be enabled when operating on batteries if no button presses are detected within a user settable time of 5, 15 or 30 minutes and via the DTR Transfer application software, the user can disable sleep mode.

The instrument can be operated from the 12 V<sub>DC</sub> AC power adapter while batteries are charging.



**NOTE:** The running of tests is not allowed when connected to the PC and the 12 V<sub>DC</sub> AC power adapter is not connected.

## 6.6. RUNNING TESTS FROM THE DTR TRANSFER APPLICATION SOFTWARE



**NOTE:** Testing is disabled if only USB-C is connected. To run a test remotely while connected to USB the 12 V<sub>DC</sub> AC power adapter must also be connected. Even when the batteries are fully charged.

### 6.6.1. Configuration Settings for Running VT/PT, CT and Continuity Tests

In this section are examples of running VT/PT, CT and Continuity tests from the DTR Transfer application software using the configurations shown in the table below.

Test Type	Set Date/Time	Set Recall Nameplate Values	Select Type	Set Filter	Set Storage Mode
VT/PT	10/10/23 10:10:10 AM	<u>Primary Voltage:</u> 19920 <u>Secondary Voltage:</u> 7200	VT/PT	Fast	Auto Save
CT	10/10/23 10:10:10 AM	<u>Primary Current:</u> 200 <u>Secondary Current:</u> 5	CT	Fast	Auto Save
Continuity	10/10/23 10:10:10 AM	<u>Primary Voltage:</u> 19920 <u>Secondary Voltage:</u> 7200	Continuity	–	Auto Save

*For Typical Connection: VT/PT see Figure 99 & Figure 100, CT see Figure 107*

Table 15

## 6.7. TIPS FOR MAKING PRECISE RATIO MEASUREMENTS

The DTR® Model 8511 is designed for step-down transformers. It sources low voltage on the primary. It starts with a fraction of the final source voltage and checks the secondary voltage.

If it exceeds the primary by a pre-determined value, the safety feature stops the measurement. The recommended procedure is to reverse the leads in these circumstances so that the primary of the transformer is connected to the H cables and the secondary of the transformer is connected to the X cables.



**WARNING:** It is important to check that the H cables are connected to the primary side and the X cables are connected to the secondary side of the transformer before the test begins.

Always verify the integrity of the cable connections and reposition the clips as necessary for robust and low-resistance connections. Inspect the transformer terminals for dielectric coatings, fungus, dirt or corrosion.

- Running a continuity test before the ratio test will provide a useful way to check windings and connections.
- When testing polyphase transformers, keep in mind that in some cases, the measured ratios must be multiplied or divided by  $\sqrt{3}$ . See § 7.2 for polyphase connection diagrams and associated ratio equations.

### 6.8. RATIO TEST - 1:1

A simple test can be conducted to test functionality of the DTR® 8511.

- Connect the H RED to X RED cable and separately connect the H BLACK to X BLACK. This connection simulates a 1:1 transformer.
- Run VT/PT test.

In this connection mode, the test results should yield a ratio nearly equal to 1.0000. If it does not, the DTR® 8511 may require repair or re-calibration.




Figure 113

# 7. CONNECTIONS

## 7.1. CONNECTION DIAGRAMS

Make sure that the HRED lead is always connected such that it does not short to the XRED or XBLACK lead directly or through earth ground.

In the diagrams below, the top three are good connections but the bottom two should be avoided.

### Measurements - OK




Figure 114

### Measurements - NOT OK



Figure 115

## 7.2. POLYPHASE CONNECTIONS

REF NO.	- TRANSFORMER -		XFMR TYPE	PHASE	HIGH VOLTAGE WINDING	LOW VOLTAGE WINDING	TURNS RATIO
	HIGH VOLTAGE WINDING	LOW VOLTAGE WINDING					
1			1 Ø STD	1 Ø	H <sub>1</sub> - H <sub>2</sub>	X <sub>1</sub> - X <sub>2</sub>	$\frac{V_H}{V_X}$
2			Δ - Δ STD	A	H <sub>1</sub> - H <sub>3</sub> (A)	X <sub>1</sub> - X <sub>3</sub> (a)	$\frac{V_H}{V_X}$
				B	H <sub>2</sub> - H <sub>1</sub> (B)	X <sub>2</sub> - X <sub>1</sub> (b)	
				C	H <sub>3</sub> - H <sub>2</sub> (C)	X <sub>3</sub> - X <sub>2</sub> (c)	
3			Δ - Δ REV	A	H <sub>1</sub> - H <sub>3</sub> (A)	X <sub>1</sub> - X <sub>3</sub> (a)	$\frac{V_H}{V_X}$
				B	H <sub>2</sub> - H <sub>1</sub> (B)	X <sub>2</sub> - X <sub>1</sub> (b)	
				C	H <sub>3</sub> - H <sub>2</sub> (C)	X <sub>3</sub> - X <sub>2</sub> (c)	
4			Δ - Y STD	A	H <sub>1</sub> - H <sub>3</sub> (A)	X <sub>1</sub> - X <sub>0</sub> (a)	$\frac{V_H \cdot \sqrt{3}}{V_X}$
				B	H <sub>2</sub> - H <sub>1</sub> (B)	X <sub>2</sub> - X <sub>0</sub> (b)	
				C	H <sub>3</sub> - H <sub>2</sub> (C)	X <sub>3</sub> - X <sub>0</sub> (c)	
5			Δ - Y REV	A	H <sub>1</sub> - H <sub>3</sub> (A)	X <sub>1</sub> - X <sub>0</sub> (a)	$\frac{V_H \cdot \sqrt{3}}{V_X}$
				B	H <sub>2</sub> - H <sub>1</sub> (B)	X <sub>2</sub> - X <sub>0</sub> (b)	
				C	H <sub>3</sub> - H <sub>2</sub> (C)	X <sub>3</sub> - X <sub>0</sub> (c)	
6			Y - Y STD	A	H <sub>1</sub> - H <sub>0</sub> (A)	X <sub>1</sub> - X <sub>0</sub> (a)	$\frac{V_H}{V_X}$
				B	H <sub>2</sub> - H <sub>0</sub> (B)	X <sub>2</sub> - X <sub>0</sub> (b)	
				C	H <sub>3</sub> - H <sub>0</sub> (C)	X <sub>3</sub> - X <sub>0</sub> (c)	
7			Y - Y REV	A	H <sub>1</sub> - H <sub>0</sub> (A)	X <sub>1</sub> - X <sub>0</sub> (a)	$\frac{V_H}{V_X}$
				B	H <sub>2</sub> - H <sub>0</sub> (B)	X <sub>2</sub> - X <sub>0</sub> (b)	
				C	H <sub>3</sub> - H <sub>0</sub> (C)	X <sub>3</sub> - X <sub>0</sub> (c)	
8			Y - Δ STD	A	H <sub>1</sub> - H <sub>0</sub> (A)	X <sub>1</sub> - X <sub>2</sub> (a)	$\frac{V_H}{V_X \cdot \sqrt{3}}$
				B	H <sub>2</sub> - H <sub>0</sub> (B)	X <sub>2</sub> - X <sub>3</sub> (b)	
				C	H <sub>3</sub> - H <sub>0</sub> (C)	X <sub>3</sub> - X <sub>1</sub> (c)	
9			Y - Δ REV	A	H <sub>1</sub> - H <sub>0</sub> (A)	X <sub>1</sub> - X <sub>2</sub> (a)	$\frac{V_H}{V_X \cdot \sqrt{3}}$
				B	H <sub>2</sub> - H <sub>0</sub> (B)	X <sub>2</sub> - X <sub>3</sub> (b)	
				C	H <sub>3</sub> - H <sub>0</sub> (C)	X <sub>3</sub> - X <sub>1</sub> (c)	

Figure 116

## 8. DATAVIEW® & DTR TRANSFER APPLICATION SOFTWARE

DataView® enables a computer to connect to and interact with a variety of Chauvin Arnoux devices, including the DTR® 8511. As its name implies, the primary purpose of DataView is to view data that has been recorded by the instrument and display it as a report.

With DataView, you can:

- Connect the instrument to a computer. This connection is through USB cable.
- Display and analyze real-time data on the computer via a frames style interface.
- Download previously recorded data from the instrument.
- Configure a wide variety of instrument settings.
- Perform instrument maintenance such as erasing its content.
- Generate reports for viewing and printing data, using standard or customizable templates.

DataView includes a core set of features used by all instruments. These features are designed for viewing data, and for opening, creating, and saving reports. DataView also includes components called **Transfer** for interacting with the instrument. A **Transfer** allows you to connect to the instrument, download data, and configure the instrument's settings. Each Chauvin Arnoux product family has its own dedicated **Transfer**; you select the **Transfer(s)** you need during DataView installation.

For example, DataView includes the DTR Transfer application software specifically designed for working with DTR instruments. The DTR Transfer application software provides all the features available in the instrument's user interface, as well as many additional features.

### 8.1. INSTALLING DATAVIEW®



**DO NOT CONNECT THE INSTRUMENT TO THE PC BEFORE INSTALLING THE SOFTWARE AND DRIVERS.**



**NOTE:** When installing, the user must have Administrative access rights during the installation. The users access rights can be changed after the installation is complete. DataView® must be reinstalled for each user in a multi-user system.

- Insert the DataView USB drive into an available USB port on your computer.
- When the USB folder is open, find the file **Setup.exe** located in the root directory of the USB drive, and double-click it to run the **installation** program.
- The **DataView® Installer** screen appears.




Figure 117

In the upper left corner of the screen, choose the **language version** of the Setup interface. All Setup screens and dialogs will then immediately appear in the selected language.

- In the lower left corner are the available installation options. In addition to the DataView software, you can select **Adobe Reader**. This links to the Adobe web site where you can download the latest version of Reader. This program is required to view DataView .pdf documents.

If you select **User Manuals** and **click Show**, a list of .pdf files contained in the USB drive that accompanies DataView will display. You can then **click Open** to view a manual or **click Return** to return to the previous screen.

- To install DataView, select **DataView** in the Options list and click **Install**.

- You are now prompted to select the software you want to install.




Figure 118

Each Chauvin Arnoux product family has its own specially designed **Transfer**. If you are performing a **complete** install, by default all available Transfers are selected (a check mark next to the Transfer indicates it is selected). Transfers take up disk space on the computer; so unless you have other types of Chauvin Arnoux devices, we recommend that you select **DTR Transfer** and deselect the rest. You should also check the option **DataView Core**, which is a requirement if you plan to create DataView reports.

- After you finish selecting and deselecting Transfers and/or DataView Core, click **Next**.
- The Setup program now informs you that it is ready to install DataView. If you want to review any of your previous selections, click the **Previous** button to return to earlier screens. Otherwise, click **Install** to begin installation.
- The InstallShield program installs the selected software.
- When all programs are installed, a message appears informing you of this. Click **Finish** to return to the Setup screen
- You can now select additional Setup options to install. When finished, click **Exit**.
- The DataView folder now appears on your PC desktop, within which is the DTR Transfer application software icon  and the icon(s) for any other Transfer(s) you have installed.

You can now open the DTR Transfer application software and connect your DTR® 8511 to the computer.

## 8.2. DTR TRANSFER APPLICATION SOFTWARE

All DTR® models will interact with a PC through the DTR Transfer application software. .

Clicking the **DataView** icon in the DataView folder on your desktop opens the core DataView program. Clicking the **DTR Transfer** icon opens it:




Figure 119

In general, DataView Core features are for creating, viewing, editing, and storing DataView reports; while the DTR Transfer application software is for connecting to, configuring, viewing measurements on, and downloading data from the instrument.

You can access all DataView features through either the DataView icon or the DTR Transfer icon. For users who interact with DTR instruments, we recommend primarily using the DTR Transfer application software. However, there are situations where using the core DataView icon may be more convenient for some users, such as when viewing multiple archived reports from different Chauvin Arnoux product families.

For further information about using the DTR Transfer application software, consult the Help system that comes with the product. Access this Help by **clicking** the option **Help** in the DTR Transfer application software's menu bar at the top of the screen.

### 8.2.1. Connecting to Computer Via DTR Transfer

Before you can use the DTR Transfer application software to communicate with your DTR® 8511, you must establish a connection between the instrument and the computer.

To begin, ensure that you have installed DataView with the DTR Transfer application software. Also ensure that the required communication and connection drivers are installed on your computer. These drivers are installed as part of the DataView installation process.

- **Connect** the USB cable to the instrument and computer.
- **Double click** on the DataView Folder on your  desktop to open folder.
- **Double click** on DTR.
- The DTR Transfer will open.
- The DTR Transfer Connection window will open.




Figure 120

- When ready, **click** OK. The DTR Transfer will open to the DTR Model 8511 status screen.

## 9. MAINTENANCE

---



Except for the batteries, the instrument contains no parts that can be replaced by personnel who have not been specially trained and accredited. Any unauthorized repair or replacement of a part by an “equivalent” may gravely impair safety.

---

### 9.1. CLEANING

---



**WARNING:** To prevent electrical shock, before cleaning disconnect all inputs and disconnect the instrument from any source of electricity.

---

- Turn the instrument OFF.
- Do not submerge in water or allow water into the case.
- Use a soft cloth lightly moistened with soapy water
- Wipe with a damp cloth.
- Dry with a dry cloth.
- Never use alcohol, solvents or hydrocarbons.

### 9.2. CHARGING THE BATTERIES

---

**NOTE:** Before using the instrument for the first time, it is recommended to fully charge the battery by leaving it connected to the charger for **10 hours**. This initial charge helps condition the battery and extend its overall service life.



Please note that during charging, the instrument does not continuously update the displayed battery percentage. To see the most accurate reading, disconnect the charger and allow the unit to rest for a few minutes. This pause lets the battery stabilize, ensuring the displayed percentage more closely matches the true state of charge.

---

#### 9.2.1. Battery Type-And General Information

The DTR® 8511 includes (6) internal rechargeable AA NiMH batteries. The rated capacity of each battery is 2500 mAh according to ANSI C18.2M, Part 1. The operating voltage is 1.0 V<sub>DC</sub> to 1.35 V<sub>DC</sub> with a nominal voltage of 1.2 V<sub>DC</sub> at 20 °C.

It is not recommended for customers to replace the batteries as the assembly process of the instrument is complicated. The batteries can be replaced when the instrument is sent to the manufacturer for service or calibration.

The battery remaining charge percentage will be displayed after disconnecting the instrument from the charging supply. A red LED, embedded in the power button on the front panel of the instrument, will turn on while the instrument is being charged and will turn off when the instrument is partially or fully charged.

#### 9.2.2. Battery Charging Options

It is recommended that the user begin a charge cycle at 15 % battery life. There are two methods to charge the batteries of the DTR® 8511.

- Plug in the supplied 12 V<sub>DC</sub> AC power adapter with barrel connector.
- Plug in a USB-C connector from a PC or USB power supply.

Red LED Status in Power Button Indicates Charge Mode		
Red LED Status	Charge Mode	
Solid	Batteries are charging.	
1 s Blinking	There is a problem with the battery charger.	
OFF	Batteries are charged.	
Flashing Rapidly	Battery(s) missing or one or more are installed reversed.	
LOW BATTERY will display if test is run when batteries are low.		

Table 16

When an external power supply is connected to the instrument, the charging circuit will evaluate the batteries to determine if they should be charged.

Charging will be complete under either of these conditions:

- The battery voltage reaches a determined charge level.
- The battery has been charging for 10 h (as a safety feature to protect the batteries and the hardware).

 **NOTE:** Charging begins when the battery is at 96 % or lower.

### 9.2.3. Battery Charge Times

The table below shows the estimated time required for the battery to reach a full charge, based on its current percentage. For example, if the battery is at 40 %, the table indicates approximately how long it will take to reach 100 % under normal charging conditions.

Starting Charge Status	Reach Full (100 %) Charge Status	Target Charge Status	Reach Target Charge Status
75 %	2.5 h	(0 to 25) %	2.5 h
50 %	5 h	(0 to 50) %	5 h
25 %	7.5 h	(0 to 75) %	7 h
0 %	10 h	(0 to 100) %	10 h

Table 17

### 9.2.4. Battery Charge Percentage

The battery percentage is calculated based on a full-scale value of 1.2 V<sub>DC</sub> (100 % charge) per cell and a minimum scale value of 1.0 V<sub>DC</sub> (0 % charge) per cell.

When the battery level drops to 10 % the instrument will no longer be able to perform a test. The batteries need to be charged to at least 14 % or to override this, connect the supplied external 12 V<sub>DC</sub> power adapter.

### 9.2.5. Battery Charging Error

In the rare case of a charging error the processor may disable the charging hardware which causes the power button **red** LED indicator to turn OFF.

If the batteries are not charging properly the DTR® 8511 will direct the user on how to restart the charger hardware in an attempt to correct the error condition.

- Step 1. The below ERROR DETECTED message will display instructing the user to remove or disconnect the USB and 12 V<sub>DC</sub> power sources.




Figure 121

If the instrument powers down after Step 1 and cannot power up, please go to Step 3.

- Step 2. If the instrument remains powered after completion of Step 1, the HOLD POWER BUTTON 2 s THEN RESTART SYSTEM message will display. This message is instructing the user to power the instrument OFF by holding down the power button for 2 s, then to restart the system by again holding down the power button for 2 s. If the instrument does not power up, please go to Step 3.




Figure 122

- Step 3. If the above process was not successful the Technical Support should be contacted for further instructions.

### 9.3. UPDATING THE FIRMWARE (USB FLASH UPLOAD)

The DTR® 8511 firmware controls the features and functionality of the instrument. Chauvin Arnoux provides firmware updates free of charge to download through our DataView® DTR Transfer application software.

The instrument supports the ability to upload firmware via USB. The transfer is initiated via an update utility program or from the DTR Transfer application software directly. After the upload has completed, the instrument resets and subsequently resumes normal operations. The instrument time could be reset by this process. Memory is maintained so no loss of data should occur but it is always best to download the memory before updating the firmware.

To update the firmware, your PC must be running DataView with the DTR Transfer application software (V2.9.16216 or later).

- Power ON the instrument using external power, to ensure the instrument remains ON throughout the update procedure. Also ensure that the battery is at least 50 % charged. Do not perform an update with the instrument running on battery power, or with low battery charge. If the instrument turns OFF while firmware updating is in progress, it could become inoperative. External power with a sufficiently charged battery for backup helps minimize the risk of power interruptions during updating.
- Connect the DTR instrument to the PC using the USB cable.
- Launch the DTR Transfer.
- Click Instrument in the menu bar and select Add an Instrument, then connect the instrument using the Add an Instrument Wizard. (Press F1 if you need assistance.)
- By default, the DTR Transfer automatically checks the connected instrument's firmware. If it is out of date, the Firmware Update dialog box appears, listing the instrument and any others running out-of-date firmware. Click Update (or Select All to update multiple instruments). This displays the Firmware Upgrade dialog box listing the latest firmware revisions for the DTR DSP and microprocessor; proceed as instructed in Step 6.

If the DTR Transfer option Check automatically for new firmware for connected instruments upon start of program has been previously de-selected, the automatic firmware check does not occur. In this case, click Instrument in the menu bar. This includes the option Firmware Upgrade. If the selected instrument is running the latest firmware, this option is grayed out and inactive. If the instrument is not running the latest firmware, click Firmware Upgrade to display the Firmware Upgrade dialog box.

- Click the Start button to begin the update. During this process, status bars display the progress of the DSP and microprocessor firmware updates. (Note that if only one of these requires updating, only its status bar appears.)
- When the firmware update is complete, click the Close button to exit.

## 10. WARRANTY

---

Except as otherwise stated, our warranty is valid for **24 months** starting from the date on which the equipment was sold. The extract from our General Conditions of Sale is available on our website.

[www.group.chauvin-arnoux.com/en/general-terms-of-sale](http://www.group.chauvin-arnoux.com/en/general-terms-of-sale)

The warranty does not apply in the following cases:

- Inappropriate use of the equipment or use with incompatible equipment;
- Modifications made to the equipment without the explicit permission of the manufacturer's technical staff;
- Work done on the device by a person not approved by the manufacturer;
- Adaptation to a particular application not anticipated in the definition of the equipment or not indicated in the user's manual;
- Damage caused by shocks, falls, or floods.

# 11. COMPLIANCE

## 11.1. APPLICABLE STANDARDS

<b>IEC 60529</b>	Degrees of protection provided by enclosures (IP Code)
<b>IEC 60068-2-6</b>	Sinusoidal Vibration Testing
<b>IEC 60068-2-27</b>	Test Ea and guidance: Shock
<b>IEC 60068-2-31</b>	Test Ec: Rough handling shocks, primarily for equipment-type specimens
<b>IEC 61010-2-030</b>	Safety requirements for electrical equipment for measurement, control, and laboratory use Part 2-030: Particular requirements for equipment having testing or measuring circuits.
<b>IEC 61326-1</b>	Electrical equipment for measurement, control and laboratory use - EMC requirements – Part 1: General requirements
<b>IEC 61960-4</b>	Secondary cells and batteries containing alkaline or other non-acid electrolytes
<b>ANSI/IEEE C57.12.90</b>	Standard Test Code for Liquid-Immersed Distribution, Power, and Regulating Transformers. Methods and procedures used to test transformers to ensure they meet performance, safety, and reliability requirements.

Table 18

## 11.2. CERTIFICATIONS

The DTR® 8511 complies with LVD and CEM directives. It is CE approved.

Certifications include:

- CE
- RoHS 2 ANNEX III
- CEM
- REACH
- Prop 65
- IP 53 (Closed)
- IP 40 (Open)

## 11.3. TERM DEFINITIONS

**Deviation:** The difference in percentage between the expected result and the actual result. Values are calculated from the Nameplate value entered and the actual measurement. Ratios below the expected result are shown with a (-) negative deviation.

**Test Current:** The amount of current the DTR® 8511 provides to the Primary (H) side to perform the test.

**Ratio:** The ratio between the Primary and Secondary side of a transformer. Expressed in Turns with a colon separator. Referenced to a turn of 1 such that a five hundred to one ratio is expressed as 500.00:1.

## 11.4. ABBREVIATIONS

<b>DTR®</b>	Digital Transformer Ratiometer
<b>---</b>	unavailable parameter based on user configuration
<b>C</b>	measured excitation current
<b>CT</b>	current transformer
<b>D</b>	deviation of measurement from expected results based on the nameplate value selected
<b>EMC</b>	electromagnetic compatibility
<b>EEPROM</b>	electrically erasable programmable read-only memory
<b>EUT</b>	equipment under test
<b>LVD</b>	low voltage directive
<b>N/A</b>	unavailable value based on user configuration
<b>P</b>	primary nameplate value
<b>PC</b>	personal computer
<b>PD</b>	power delivery
<b>R</b>	ratio
<b>S</b>	secondary nameplate value
<b>UI</b>	user interface
<b>VT/PT</b>	voltage transformer/potential transformer

**Table 19**



**FRANCE**

**Chauvin Arnoux**

12-16 rue Sarah Bernhardt  
92600 Asnières-sur-Seine  
Tél : +33 1 44 85 44 85

[info@chauvin-arnoux.com](mailto:info@chauvin-arnoux.com)  
[www.chauvin-arnoux.com](http://www.chauvin-arnoux.com)

**INTERNATIONAL**

**Chauvin Arnoux**

Tél : +33 1 44 85 44 38

[export@chauvin-arnoux.fr](mailto:export@chauvin-arnoux.fr)

**Our international contacts**

[www.chauvin-arnoux.com/contacts](http://www.chauvin-arnoux.com/contacts)



**CHAUVIN  
ARNOUX**